

Instructions

Service kits

PN 16	M1	PN 25	M1	M2					
					<table border="1"> <tr> <td>M1</td> <td>CuSn5ZnPb (Rg5)</td> </tr> <tr> <td>M2</td> <td>EN-GJS-400-18-LT (GGG 40.3)</td> </tr> </table>	M1	CuSn5ZnPb (Rg5)	M2	EN-GJS-400-18-LT (GGG 40.3)
M1	CuSn5ZnPb (Rg5)								
M2	EN-GJS-400-18-LT (GGG 40.3)								

PN 16					M1
1	2	3	4	5	





